

Test Report

ITG- Integration Test Group

PR Electronics

21-September-2004

Elaboration/Revision:

Otavio Cremonez Eufrazio

Approval:

T R Nº 057

Modifications History

See Modifications History

Contents

1 **Goal** 1
2 **Test Environment** 1
 2.1 **Software** 1
3 **Test Report**..... 1
4 **Additional Comments** 2
5 **Enhancement** 3
6 **Modification History** 4

Starting Test Date	Finished Test Date
16-09-2004	21-09-2004

Tester Name _____

Otavio Cremonez Eufrazio

1 Goal

This is a Test Report from the Test Case TC-ITG-050-00

2 Test Environment

- Pentium IV – 1,7 GHz – 512 MB RAM – Windows XP - Professional

2.1 Software

- Syscon 5.23 build 22
- DFI firmware V3.8.1.2
- PR-Electronics DD Rev: 5350 : Version 0201
6350 : Version 0102

3 Test Report

Test case reference	Status		Tester Name	Trouble Report
	Test	Retest		
TC-ITG-066-00	OK		Otavio	See additional comments 1

4 Additional Comments

Item	Tester Name	Additional Comment
01	Otavio	It happened sometimes that we can't write the value "Manual" in the Mode_Blk.Target of the Analog Input block. However it accepted the write request if repeat it once or twice. This defect is not reproducible deterministically

5 Enhancement

Item	Tester Name	Additional Comment
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		

6 Modification History

REV.	ELABORATED	APPROVED	DESCRIPTION:
00	Otavio Cremones Eufrazio 20-09-2004	William Durate Ferraz 20-09-2004	First issue.
REV.	ELABORATED	APPROVED	DESCRIPTION:
01	[Click and insert name] [Month day, year]	[Click and insert name] [Month day, year]	[Click here and insert description]
REV.	ELABORATED	APPROVED	DESCRIPTION:
[No.]	[Click and insert name] [Month day, year]	[Click and insert name] [Month day, year]	[Click here and insert description] .
REV.	ELABORATED	APPROVED	DESCRIPTION:
[No.]	[Click and insert name] [Month day, year]	[Click and insert name] [Month day, year]	[Click here and insert description] .
REV.	ELABORATED	APPROVED	DESCRIPTION:
[No.]	[Click and insert name] [Month day, year]	[Click and insert name] [Month day, year]	[Click here and insert description] .

Test Case Specification
Group

ITG- Integration Test

**Device Stress Test – 0007D0 – 0080
and 0081**

TC Nº 066

13-September-2004

Elaboration/Revision:

Otavio C. E./William D.F.

Approval:

Modifications History:

See Modifications History

Contents

1	Goal	1
2	References Documents.....	1
3	Test Procedures.....	1
3.1	FF Strategy	1
3.1.1	Block Type Limit	1
3.1.2	Blocks Limit.....	1
3.1.3	Link Limit	2
3.1.4	Block Type Test.....	2
3.2	Operational Characteristics.....	3
3.2.1	Temperature Reading	3
	Modification History	4

Device Stress Test – PR Electronics

1 Goal

Test all functions and limits of PR Electronics.

2 References Documents

No documents to references.

3 Test Procedures

3.1 FF Strategy

3.1.1 Block Type Limit

3.1.1.1 References

The references are the Test Plan.

3.1.1.2 Description

The objective of this procedure is create one block of each type and see the behavior of PR Electronics and Syscon.

3.1.1.3 Pre-conditions

The user should know how to make a ff configuration in SYSTEM302.

3.1.1.4 Procedure

- 3.1.1.4.1 Open Syscon.
- 3.1.1.4.2 Create a new project, then a new bridge and finally a Pretop 5350.
- 3.1.1.4.3 Create one block of each type.
- 3.1.1.4.4 Go online and assign the right ID to the device.
- 3.1.1.4.5 Press the Toggles Detail On.
- 3.1.1.4.6 Start a download and check if download finish with no failure.
- 3.1.1.4.7 Check the macro cycle calculated by Syscon.
- 3.1.1.4.8 Compare this number with the macro cycle gave by the expression $[(\text{no. of devices} * 30) + (\text{no. of external links} * 30)] * 1,2$.
- 3.1.1.4.9 Using the FBView check if the number of the Macro Cycle is right during the supervision.
- 3.1.1.4.10 Repeat all the steps to the Pretrans 6350.

3.1.2 Blocks Limit

3.1.2.1 References

The references are the Test Plan.

3.1.2.2 Description

The objective of this procedure is create the maximum number of blocks allowed and see the behavior of PR Electronics and Syscon.

3.1.2.3 Pre-conditions

The user should know how to work SYSTEM302.

3.1.2.4 Procedure

- 3.1.2.4.1 Open Syscon.
- 3.1.2.4.2 Create a new project, then a new bridge and finally a Pretop 5350.
- 3.1.2.4.3 Create blocks as much as the limit of the device.
- 3.1.2.4.4 Go online and assign the right ID to the device.
- 3.1.2.4.5 Press the Toggles Detail On.
- 3.1.2.4.6 Start a download and check if download finish with no failure.
- 3.1.2.4.7 Check the macro cycle calculated by Syscon.
- 3.1.2.4.8 Compare this number with the macro cycle gave by the expression $[(\text{no. of devices} * 30) + (\text{no. of external links} * 30)] * 1,2$.
- 3.1.2.4.9 Using the FBView check if the number of the Macro Cycle is right during the supervision.
- 3.1.2.4.10 Repeat all the steps to the Pretrans 6350.

3.1.3 Link Limit

3.1.3.1 References

The references are the Test Plan.

3.1.3.2 Description

The objective of this procedure is create the maximum number of links allowed and see the behavior of PR Electronics and Syscon.

3.1.3.3 Pre-conditions

The user should know how to work SYSTEM302.

3.1.3.4 Procedure

- 3.1.3.4.1 Open Syscon.
- 3.1.3.4.2 Create a new project, then a new bridge and finally a PR Electronics.
- 3.1.3.4.3 Create some blocks.
- 3.1.3.4.4 Create another device (anyone).
- 3.1.3.4.5 Create some blocks.
- 3.1.3.4.6 Make a total of 50 internal links.
- 3.1.3.4.7 Go online and assign the right ID to the device.
- 3.1.3.4.8 Press the Toggles Detail On.
- 3.1.3.4.9 Start a download and check if download finish with no failure.
- 3.1.3.4.10 Check the macro cycle calculated by Syscon.
- 3.1.3.4.11 Compare this number with the macro cycle gave by the expression $[(\text{no. of devices} * 30) + (\text{no. of external links} * 30)] * 1,2$.
- 3.1.3.4.12 Using the FBView check if the number of the Macro Cycle is right during the supervision.
- 3.1.3.4.13 Repeat the steps 3.1.3.4.1 to 3.1.3.4.5
- 3.1.3.4.14 Create 50 links (17 external links (publisher), 12 external links (subscriber) and 21 internal links).
- 3.1.3.4.15 Go online and assign the right ID to the device.
- 3.1.3.4.16 Press the Toggles Detail On.
- 3.1.3.4.17 Start a download and check if download finish with no failure.
- 3.1.3.4.18 Check the macro cycle calculated by Syscon.
- 3.1.3.4.19 Compare this number with the macro cycle gave by the expression $[(\text{no. of devices} * 30) + (\text{no. of external links} * 30)] * 1,2$.
- 3.1.3.4.20 Using the FBView check if the number of the Macro Cycle is right during the supervision.
- 3.1.3.4.21 Repeat all the steps to the Pretrans 6350.

3.1.4 Block Type Test

3.1.4.1 References

The references are the Test Plan.

3.1.4.2 Description

The objective of this procedure is test the functionality of each block.

3.1.4.3 Pre-conditions

The user should know how to work SYSTEM302.

3.1.4.4 Procedure

- 3.1.4.4.1 Open Syscon.
- 3.1.4.4.2 Create a new project, then a new bridge and finally a Pretop 5350.
- 3.1.4.4.3 Create one block.
- 3.1.4.4.4 Go online and assign the right ID to the device.
- 3.1.4.4.5 Press the Toggles Detail On.
- 3.1.4.4.6 Start a download and check if download finish with no failure.
- 3.1.4.4.7 Check the macro cycle calculated by Syscon.
- 3.1.4.4.8 Compare this number with the macro cycle gave by the expression $[(\text{no. of devices} * 30) + (\text{no. of external links} * 30)] * 1,2$.
- 3.1.4.4.9 Using the FBView check if the number of the Macro Cycle is right during the supervision.
- 3.1.4.4.10 Check if all parameters is ok and the Syscon is showing all values.
- 3.1.4.4.11 Check all parameters making some writings and changing some values (only in the RW parameters).
- 3.1.4.4.12 Check if these changes result in what were expect.
- 3.1.4.4.13 Repeat the steps 3.1.4.4.3 to 3.1.4.4.12 to all blocks supported.

3.1.4.4.14 Repeat all the steps to the Pretrans 6350.

3.2 Operational Characteristics

3.2.1 Temperature Reading

3.2.1.1 References

The references are the Test Plan.

3.2.1.2 Description

The objective of this procedure is test the temperature reading of the device.

3.2.1.3 Pre-conditions

The user should know how to work SYSTEM302.

3.2.1.4 Procedure

3.2.1.4.1 Open Syscon.

3.2.1.4.2 Create a new project, then a new bridge and finally a Pretop 5350.

3.2.1.4.3 Create a Resource, Transducer, Analog Input and a PID block.

3.2.1.4.4 Go online and assign the right ID to the device.

3.2.1.4.5 Press the Toggles Detail On.

3.2.1.4.6 Start a download and check if download finish with no failure.

3.2.1.4.7 Using the Demo Kit, simulate some temperatures values

3.2.1.4.8 Check if it is consistent with the block reading.

3.2.1.4.9 Repeat all the steps to the Pretrans 6350.

Modification History

REV. 00	ELABORATED Otavio Cremones Eufrazio May 05, 2004	APPROVED _____	DESCRIPTION: First issue
REV. [No.]	ELABORATED [Click and insert name] [Month day, year]	APPROVED [Click and insert name] [Month day, year]	DESCRIPTION: [Click here and insert description]
REV. [No.]	ELABORATED [Click and insert name] [Month day, year]	APPROVED [Click and insert name] [Month day, year]	DESCRIPTION: [Click here and insert description] .
REV. [No.]	ELABORATED [Click and insert name] [Month day, year]	APPROVED [Click and insert name] [Month day, year]	DESCRIPTION: [Click here and insert description] .
REV. [No.]	ELABORATED [Click and insert name] [Month day, year]	APPROVED [Click and insert name] [Month day, year]	DESCRIPTION: [Click here and insert description] .