



5337

2-wire Transmitter with HART® Protocol

No. 5337V100-UK From ser. no. 120917007













SIGNALS THE BEST

- ▶ PR electronics A/S tilbyder et bredt program af analoge og digitale signalbehandlingsmoduler til industriel automation. Programmet består af Isolatorer, Displays, Ex-barrierer, Temperaturtransmittere, Universaltransmittere mfl. Vi har modulerne, du kan stole på i selv barske miljøer med elektrisk støj, vibrationer og temperaturudsving, og alle produkter opfylder de strengeste internationale standarder. Vores motto »Signals the Best« er indbegrebet af denne filosofi og din garanti for kvalitet.
- UK PR electronics A/S offers a wide range of analogue and digital signal conditioning devices for industrial automation. The product range includes Isolators, Displays, Ex Interfaces, Temperature Transmitters, and Universal Devices. You can trust our products in the most extreme environments with electrical noise, vibrations and temperature fluctuations, and all products comply with the most exacting international standards. »Signals the Best« is the epitome of our philosophy and your guarantee for guality.
- FR ▶ PR electronics A/S offre une large gamme de produits pour le traitement des signaux analogiques et numériques dans tous les domaines industriels. La gamme de produits s'étend des transmetteurs de température aux afficheurs, des isolateurs aux interfaces SI, jusqu'aux modules universels. Vous pouvez compter sur nos produits même dans les conditions d'utilisation sévères, p.ex. bruit électrique, vibrations et fluctuations de température. Tous nos produits sont conformes aux normes internationales les plus strictes. Notre devise »SIGNALS the BEST« c'est notre ligne de conduite et pour vous l'assurance de la meilleure qualité.
- PR electronics A/S verfügt über ein breites Produktprogramm an analogen und digitalen Signalverarbeitungsmodule für die industrielle Automatisierung. Dieses Programm umfasst Displays, Temperaturtransmitter, Ex- und galvanische Signaltrenner, und Universalgeräte. Sie können unsere Geräte auch unter extremen Einsatzbedingungen wie elektrisches Rauschen, Erschütterungen und Temperaturschwingungen vertrauen, und alle Produkte von PR electronics werden in Übereinstimmung mit den strengsten internationalen Normen produziert. »Signals the Best« ist Ihre Garantie für Qualität!

# 2-WIRE TRANSMITTER WITH HART® PROTOCOL

# PRetop 5337

## **CONTENTS**

EC declaration of conformity	2
Application	3
Technical characteristics	3
Mounting / installation / programming	4
Applications	5
Accessories	6
Ordering codes for 5337	6
Technical data	6
Switching HART® protocol revision	9
Connections	11
Block diagram	12
Programming	13
Connection of transmitters in multidrop mode	15
Mechanical specifications	15
Mounting of sensor wires	15
Appendix	16
ATEX Installation Drawing - 5337A	17
IECEx Installation Drawing - 5337A	18
ATEX Installation Drawing - 5337D	19
IECEx Installation Drawing - 5337D	21
FM Installation Drawing - 5337D	23
CSA Installation Drawing - 5337D	25

#### EC DECLARATION OF CONFORMITY

As manufacturer

PR electronics A/S Lerbakken 10 DK-8410 Rønde

hererby declares that the following product:

Type: 5337

Name: 2-wire transmitter with HART® protocol

is in conformity with the following directives and standards:

The EMC Directive 2004/108/EC and later amendments

EN 61326-1: 2006

For specification of the acceptable EMC performance level, refer to the electrical specifications for the device.

The ATEX Directive 94/9/EC and later amendments

EN 60079-0 : 2009, EN 60079-11 : 2007, EN 60079-15 : 2010, EN 60079-26 : 2007

and EN 61241-11 : 2006.

ATEX certificate: KEMA 03ATEX1508 X (5337A) ATEX certificate: KEMA 03ATEX1537 (5337D)

Notified body

DEKRA Certification B.V. (0344) Utrechtseweg 310, 6812 AR Arnhem P.O. Box 5185, 6802 ED Arnhem The Netherlands

Rønde, 23 March 2012

Kim Rasmussen Manufacturer's signature

# PRetop 5337 2-WIRE TRANSMITTER WITH HART® PROTOCOL

- RTD, TC, Ohm, or mV input
- 2 analogue inputs and 5 device variables with status available
- HART® protocol revision selectable from HART® 5 or HART® 7
- Hardware assessed for use in SIL applications
- Mounting on a DIN rail in safe area or hazardous gas and dust area

## Application

- Linearised temperature measurement with TC and RTD sensors like e.g. Pt100 and Ni100.
- HART<sup>®</sup> communication and 4...20 mA analogue PV output for individual, difference or average temperature measurement of up to two RTD or TC input sensors.
- Conversion of linear resistance variation to a standard analogue current signal, for instance from valves or Ohmic level sensors.
- Amplification of a bipolar mV signal to a standard 4...20 mA current signal.
- Up to 63 transmitters can be connected in a multidrop communication setup (HART® 7).


#### Technical characteristics

- The HART® protocol revision can be changed by user configuration to either HART® 5 or HART® 7 protocol.
- HART<sup>®</sup> 7 protocol offers:
  - · Long tag supported (up to 32 characters).
  - · Enhanced Burst Mode and Event Notification with time stamping possibillity.
  - Device variables with status, can be mapped individually to any dynamic variable PV. SV. TV or QV.

- · Measuring of trending in the process signal.
- · Automatic event notification with time stamps.
- · Command aggregation for higher communication efficiency.
- 5337 is designed according to strict safety requirements and is thus suitable for applications in SIL installations.
- · Continuous check of vital stored data.
- Sensor error detection according to the guidelines in NAMUR NE 89.

## Mounting / installation / programming

- For DIN form B sensor head or DIN rail mounting via the PR fitting type 8421.
- Configuration via HART<sup>®</sup> tool or by PR 5909 Loop Link.
- NB: As Ex barrier for 5337D we recommend 5106B and 9106B



#### Ordering codes for 5337 \_

Туре	Version
5337	Standard:

#### Accessories

5909 = Loop Link USB interface and PReset Software 8421 = DIN rail clip

#### Technical data

#### **Environmental conditions:**

Specifications range	-40°C to +85°C
Calibration temperature	2028°C
Relative humidity	< 95% RH (non-cond.)
Protection degree	IP68/IP00
Vibration	IEC 60068-2-6 Test FC
Lloyd's specification no. 1	4 g / 2100 Hz

## Mechanical specifications:

Dimensions	Ø 44 x 20.2 mm
Weight approx	50 g
Max. wire size	1 x1.5 mm <sup>2</sup> stranded wire
Screw terminal torque	0.4 Nm

#### Common electrical specifications:

Supply voltage, DC:	
Standard	8.035 V
ATEX, CSA, FM, IECEx & INMETRO	8.030 V
Voltage drop	8.0 V
Isolation - test / working	1.5 kVAC / 50 VAC
Signal / noise ratio	
Communications interface	Loop Link & HART®
Response time (programmable)	160 s

#### Accuracy, the greater of general and basic values:

General values			
Absolute Temperature Input type accuracy coefficient			
All	$\leq \pm 0.05\%$ of span	$\leq$ ±0.005% of span / °C	

Basic values			
Input type	Basic accuracy	Temperature coefficient	
Pt50 - Pt1000	≤ ±0.1°C	≤ ±0.005°C/°C	
Ni50 - Ni1000	≤ ±0.2°C	≤ ±0.005°C/°C	
Lin. R	≤ ±0.1 Ω	$\leq$ ±5 m $\Omega$ / °C	
Volt	≤ ±10 µV	≤ ±0.5 µV / °C	
TC type: E, J, K, L, N, T, U	≤ ±0.5°C	≤ ±0.025°C / °C	
TC type: B <sup>1</sup> , Lr, R, S, W3, W5	≤ ±1°C	≤ ±0.1°C / °C	
TC type:B <sup>2</sup>	≤ ±3°C	≤ ±0.3°C / °C	
TC type:B <sup>3</sup>	≤ ±8°C	≤ ±0.8°C / °C	
TC type:B4	not specified	not specified	

TC B $^1$  accuracy specification range....... > 400°C TC B $^2$  accuracy specification range....... > 160°C < 400°C TC B $^3$  accuracy specification range ....... > 85°C < 160°C

TC B<sup>4</sup> accuracy specification range ....... < 85°C

TC cold junction compensation ...... < ±1.0°C

Max. offset on input signal...... 50% of selec. max. value

EMC immunity influence ...... < ±0.1% of span

Extended EMC immunity:

NAMUR NE 21, A criterion, burst ...... < ±1% of span

### Input specifications:

RTD input types:

Pt50, Pt100, Pt200, Pt500, Pt1000, Ni50, Ni100, Ni120, Ni1000

Cable resistance per wire (max.)............................ 50  $\Omega$ 

Sensor current...... Nom. 0.2 mA

RTD	Min.	Max.	Min.	Standard
type	value	values	span	
Pt100 Ni100 Lin. R	-200°C -60°C 0 Ω	+850°C +250°C 7000 Ω	10°C 10°C 25 Ω	IEC 60751 DIN 43760

## TC input types:

Туре	Min. temperature	Max. temperature	Min. span	Standard
BEJKLLNRSTU33W5	0°C -100°C -100°C -180°C -200°C -200°C -180°C -50°C -50°C -200°C 0°C 0°C	+1820°C +1000°C +1200°C +1372°C +900°C +800°C +1300°C +1760°C +1760°C +400°C +2300°C +2300°C	100°C 50°C 50°C 50°C 50°C 50°C 100°C 100°C 50°C 100°C 100°C	IEC584 IEC584 IEC584 IEC584 DIN 43710 GOST 3044-84 IEC584 IEC584 IEC584 IEC584 IEC584 IEC584 ODIN 43710 ASTM E988-90

Cold junction compensation (CJC):

Constant, internal or external via a Pt100 or Ni100 sensor

Voltage input range .....-800 mV

## Output specifications and HART®:

Signal range	420 mA
Min. signal range	
Updating time	
Load resistance	$\leq (V_{SUDDIV} - 8) / 0.023 [\Omega]$
Sensor error detection, programmable	3.523mA
HART® protocol revisions	HART® 5 and HART® 7

## Switching HART® protocol revision

It is possible to change the HART® protocol revision by using the PReset software and a PR 5909 Loop Link interface or a HART® compatible modem. Other HART® configuration tools like a handheld terminal can also be used.

## Switching from HART® 7 to HART® 5:

Procedure when using the PR PReset Software:

Enter the PReset tab "HART" and open the folder "Methods".

Press the "Device Password / Write Protection / Protocol..." line and select "change protocol to HART5" - acknowledge by pressing OK.

## Procedure when using alternative HART® tools:

Write-protect the device and set the new password to "HARTREV5". Write-enable the device by using the password "-CHANGE-".

Please note that this will change the 5337 device to a 5335 HART device.

## Switching from HART® 5 to HART® 7:

Write-protect the device and set the new password to "HARTREV7". Write-enable the device by using the password "-CHANGE-"

Please note that this is only possible if the transmitter is marked "5337".

This will reset the password to the default active password ("\*\*\*\*\*\*\*") and restart the device in the updated mode with write protection disabled.

**Please note** that the configuration changed flags and configuration changed counter are **not** updated by this command.

### Approvals:

EMC 2004/108/EC	EN 61326-1
GOST R	

## Ex / I.S.:

F	2	3	7	^	
U	v	v	1	$\overline{}$	١.


5337A:	
ATEX 94/9/EC	KEMA 03ATEX1508 X
IECEx	KEM 10.0083 X
5337D:	
ATEX 94/9/EC	KEMA 03ATEX1537 X
IECEx	KEM 10.0083 X
FM certificate	2D5A7
CSA certificate	1125003
INMETRO certificate	09/UL-BRCO-0002
GOST Ex	

## **Functional Safety:**


Hardware assessed for use in SIL applications FMEDA report - www.prelectronics.com

## CONNECTIONS

# Input:



# **BLOCK DIAGRAM**



#### **PROGRAMMING**


#### 5337 can be configured in the following 3 ways:

- With PR electronics A/S' communications interface Loop Link and PReset PC configuration software.
- 2. With a HART® modem and PReset PC configuration software.
- 3. With a HART® communicator with PR electronics A/S' DDL driver.

#### 1: Loop Link


For programming please refer to the drawing below and the help functions in PReset.

Loop Link is not approved for communication with devices installed in hazardous (Ex) areas.




#### 2: HART® modem

For programming please refer to the drawing below and the help functions in PReset




#### 3: HART® communicator

For programming please refer to the drawing below. To gain access to product-specific commands, a suitable HART® communicator must be loaded with the PR electronics A/S DDL driver. This can be ordered either at the HART® Communication Foundation or at PR electronics A/S.



# CONNECTION OF TRANSMITTERS IN MULTIDROP MODE

The HART® communicator or a PC modem can be connected accross AB or BC.




The outputs of max. 63 transmitters can be connected in parallel for a digital HART® 7 communication on 2-wires.


Before it is connected, each transmitter must be configured with a unique number from 1 to 63. If 2 transmitters are configured with the same number, both will be excluded. The transmitters must be programmed for multidrop mode (with a fixed output signal of 4 mA). Maximum current in the loop is therefore 252 mA.

The communication is either by means of a HART® communicator or a HART® modem.


The PReset PC configuration software can configure the individual transmitter for multidrop mode and provide it with a unique polling address.

## **Mechanical specifications**





## Mounting of sensor wires



# **APPENDIX**

ATEX Installation Drawing - 5337A

IECEx installation drawing - 5337A

ATEX Installation Drawing - 5337D

IECEx installation drawing - 5337D

FM Installation Drawing No. 5300Q502

CSA Installation Drawing No. 533XQC03



WWW PREI ECTRONICS COM

## ATEX Installation drawing

For safe installation of 5335A, 5336A or 5337A the following must be observed. The module shall only be installed by qualified personnel who are familiar with the national and international laws, directives and standards that apply to this area.

Year of manufacture can be taken from the first two digits in the serial number.

ATEX Certificate KEMA 03ATEX 1508X

Marking

II 3 G Ex nA [ic] IIC T6..T4 Gc
II 3 G Ex ic IIC T6..T4 Gc
II 3 D Ex ic IIIC Dc

Standards EN60079-0:2009, EN60079-11:2007, EN60079-15:2010 EN61241-11:2006

T4: -40 ≤ Ta ≤ 85°C Terminal: 3.4.5.6 Terminal: 1.2 Terminal: 1.2 T6: -40 < Ta < 60°C Ex nA [ic] Fx nA Ex ic Un: 9 6 V Ui = 35 VDC U < 35 VDC In: 28 mA I = 4 - 20 mALi = 10 uH Po: 67 mW Ci = 1.0 nF Lo: 45 mH Co: 28 uF

#### Installation note:

For use in an explosive dust atmosphere, the transmitter shall be mounted in an enclosure providing a degree of protection of at least IP6X in accordance with EN60529, eg. a form B enclosure according to DIN 43729. The surface of the enclosure is equal to the ambient temperature + 20K. for a dust laver with a maximum thickness of 5 mm.

#### Special conditions for safe use:

For use in an explosive gas atmosphere, the transmitter shall be mounted in an enclosure providing a degree of protection of at least IP54 in accordance with EN60529.

For an ambient temperature  $\ge$  60 °C, heat resistant cables shall be used with a rating of at least 20K above the ambient temperature.

 Revision date:
 Version Revision
 Page:

 2011-02-01
 V3R0
 1/1



WWW PREI ECTRONICS COM

## IECEx Installation drawing



For safe installation of 5335A, 5336A or 5337A the following must be observed. The module shall only be installed by qualified personnel who are familiar with the national and international laws, directives and standards that apply to this area.

Year of manufacture can be taken from the first two digits in the serial number.

IECEx Certificate IECEx KEM 10.0083X

Marking \_

Ex nA [ic] IIC T6..T4 Gc Ex ic IIC T6..T4 Gc

Ex ic IIIC Dc

Standards IEC 60079-0 : 2007, IEC 60079-11 : 2006, EN 60079-15 : 2010

T4: -40 ≤ Ta ≤ 85°C Terminal: 3.4.5.6 Terminal: 12 Terminal: 12 T6: -40 ≤ Ta ≤ 60°C Ex nA fic1 Fx nA Ex ic Un: 96 V U ≤ 35 VDC Ui = 35 VDC In: 28 mA I = 4 - 20 mA $Li = 10 \mu H$ Po: 67 mW Ci = 1.0 nF

Lo: 45 mH Co: 28 μF

#### Installation note:

For installation in a potentialy explosive gas atmosphere, the following instructions apply:

The transmitter shall be installed in an enclosure providing a degree of protection of at least IP54 according to IEC60529 or in an enclosure with type of protection Ex n or Ex e. Cable entry devices and blanking elements shall fulfill the same requirements For an ambient temperature > 60°C, heat resistant cables shall be used with a rating of at least 20 K above the ambient temperature.

For installation in a potentially explosive dust atmposphere, the following instructions apply: If the transmitter is supplied with an intrinsically safe signal "ic" and interfaces an intrinsically safe signal "ic" (e.g. a passive device), the transmitter shall be mounted in a metal enclosure form B according to DIN 43729 that provides a degree of protection of at least IP6X according to IEC60529, and that is suitable for the application. Cable entry devices and blanking elements shall fulfill the same requirements.

If the transmitter is supplied with an non-sparking signal "nA", or interfaces a nonsparking signal, the transmitter shall be mounted in a metal enclosure form B according to DIN 43729 providing a degree of protection of at least IP6X according to IEC60529, and in conformance with type of protection Ex tD and suitable for the application. Cable entry devices and blanking elements shall fulfill the same requirements.

 Revision date:
 Version Revision
 Page:

 2011-02-01
 V3R0
 1/1



WWW.PRELECTRONICS.COM

#### ATEX Installation drawing



For safe installation of 5335D, 5336D or 5337D the following must be observed. The module shall only be Installed by qualified personnel who are familiar with the national and international laws, directives and standards that apply to this area.

Year of manufacture can be taken from the first two digits in the serial number.

ATFX Certificate

KEMA 03ATEX 1537


Marking

(ξ<sub>x</sub>)

II 1 G Ex ia IIC T6 ...T4 Ga II 1 D Ex ia IIIC Da I M1 Ex ia I Ma

Standards

EN 60079-0 : 2009, EN 60079-11 : 2007, EN 60079-26 : 2007, EN 61241-11: 2006



Revision date: 2011-02-01 Version Revision V3R0 Page: 1/10

D---



#### LERBAKKEN 10. 8410 RØNDE DENMARK.

WWW.PRELECTRONICS.COM

#### Installation notes.

For installation in a potentially explosive gas atmosphere, the following instructions apply:

The sensor circuit is not infallibly galvanic isolated from the supply output circuit. However, the galvanic isolation between the circuits is capable of withstanding a test voltage of 500Vac during 1 minute.

The transmitter shall be mounted in an enclosure form B according to DIN43729 or equivalent that is providing a degree of protection of at least IP20 according to EN60529 that is suitable for the application and correctly installed.

If the enclosure is made of aluminium, it must be installed such, that even in the event of rare incidents, ignition sources due to impact and friction, sparks are excluded.

If the enclosure is made of non-metallic materials, electrostatic charging shall be avoided.

For installation in a potentially explosive dust atmosphere, the following instructions apply:

The transmitter shall be mounted in a metal enclosure form B according to DIN43729 or equivalent, that is providing a degree of protection of at least IP6X according to EN60529 that is suitable for the application and correctly installed.

Cable entries and blanking elements shall be used that are suitable for the application and correctly installed.

For an ambient temperature ≥ 60°C, heat resistant cables shall be used with a rating of at least 20 K above the ambient temperature.

For installalation in mines the following instructions apply:

The transmitter shall be mounted in a metal enclosure that is providing a degree of protection of at least IP6X according to EN60529, and is suitable for the application and correctly installed.

Cable entries and blanking elements shall be used that are suitable for the application and correctly installed

The enclosure shall not contain by mass more than

a) 15 % in total of aluminium, magnesium, titanium and zirconium, and

b) 7.5 % in total of magnesium, titanium and zirconium.

Revision date.	Version Revision	Page.
2011-02-01	V3R0	2/10

Version Devision

Davisias data



WWW.PRELECTRONICS.COM

#### **IECEx Installation drawing**



For safe installation of 5335D, 5336D or 5337D the following must be observed. The module shall only be Installed by qualified personnel who are familiar with the national and international laws, directives and standards that apply to this area.

Year of manufacture can be taken from the first two digits in the serial number.


IECEx Certificate IECEx KEM 10.0083X

Marking Ex ia IIC T6..T4 Ga

Ex ia I Ma

Standards IEC60079-11:2006, IEC60079-0: 2007

IEC60079-26:2006, IEC61241-11:2005



 Revision date:
 Version Revision
 Page:

 2011-02-01
 V3R0
 3/10



WWW.PRELECTRONICS.COM

#### Installation notes.

For installation in a potentially explosive gas atmosphere, the following instructions apply:

The sensor circuit is not infallibly galvanic isolated from the supply output circuit. However, the galvanic isolation between the circuits is capable of withstanding a test voltage of 500Vac during 1 minute.

The transmitter shall be mounted in an enclosure form B according to DIN43729 or equivalent that is providing a degree of protection of at least IP20 according to IEC 60529 that is suitable for the application and correctly installed.

If the enclosure is made of aluminium, it must be installed such, that even in the event of rare incidents, ignition sources due to impact and friction, sparks are excluded.

If the enclosure is made of non-metallic materials, electrostatic charging shall be avoided.

For installation in a potentially explosive dust atmosphere, the following instructions apply:

The transmitter shall be mounted in a metal enclosure form B according to DIN43729 or equivalent, that is providing a degree of protection of at least IP6X according to IEC 60529 that is suitable for the application and correctly installed.

Cable entries and blanking elements shall be used that are suitable for the application and correctly installed.

For an ambient temperature  $\geq$  60°C, heat resistant cables shall be used with a rating of at least 20 K above the ambient temperature.

For installalation in mines the following instructions apply:

The transmitter shall be mounted in a metal enclosure that is providing a degree of protection of at least IP6X according to IEC 60529, and is suitable for the application and correctly installed

Cable entries and blanking elements shall be used that are suitable for the application and correctly installed

The enclosure shall not contain by mass more than

a) 15 % in total of aluminium, magnesium, titanium and zirconium, and


b) 7,5 % in total of magnesium, titanium and zirconium.




WWW PRELECTRONICS COM

#### FM Installation Drawing 5300Q502 Rev AG

#### Model 5331C.5331D, 5333C and 5333D



#### Model 5335C, 5335D, 5336D,5337D,



 Revision date:
 Version Revision
 Page:

 2011-02-01
 V3R0
 5/10



WWW PRELECTRONICS COM

#### The entity concept.

The Transmitter must be installed according to National Electrical Code (ANSI-NFPA 70) and shall be installed with the enclosure, mounting, and spacing segregation requirement of the ultimate application.

Equipment that is FM-approved for intrinsic safety may be connected to barriers based on the ENTITY CONCEPT. This concept permits interconnection of approved transmitters, meters and other devices in combinations which have not been specifically examined by FM, provided that the agency's criteria are met. The combination is then intrinsically safe, if the entity concept is acceptable to the authority having jurisdiction over the installation.

The entity concept criteria are as follows:

The intrinsically safe devices, other than barriers, must not be a source of power.

The maximum voltage  $Ui(V_{MAX})$  and current  $Ii(I_{MAX})$ , and maximum power Pi(Pmax), which the device can receive and remain intrinsically safe, must be equal to or greater than the voltage  $(Uo \text{ or } V_{OC} \text{ or } V_i)$  and current  $(Io \text{ or } I_{SC} \text{ or } I_i)$  and the power Po which can be delivered by the barrier.


The sum of the maximum unprotected capacitance  $(C_i)$  for each intrinsically device and the interconnecting wiring must be less than the capacitance  $(C_a)$  which can be safely connected to the barrier.

The sum of the maximum unprotected inductance  $(L_i)$  for each intrinsically device and the interconnecting wiring must be less than the inductance  $(L_a)$  which can be safely connected to the barrier.

The entity parameters  $Uo,V_{OC}$  or  $V_t$  and  $Io,I_{SC}$  or  $I_t$ , and  $C_a$  and  $L_a$  for barriers are provided by the barrier manufacturer.

#### NI Field Circuit Parameters

#### Model 5331C, 5331D, 5333C, 5333D, 5335C, 5335D, 5336D,5337D



 Revision date:
 Version Revision
 Page:

 2011-02-01
 V3R0
 6/10




WWW PRELECTRONICS COM

#### CSA Installation Drawing 533XQC03.

5331D, 5333D, 5335D, 5336D and 5337D transmitters are intrinsically safe in Zone 0 Group IIC or Class I.Division1.Group A.B.C.D when installed according to Installation Drawing.

# Connections with separate power supply and receiver. Output: Standard 4 - 20mA loop



#### Warning:

Substitution of components may impair intrinsic safety.

The transmitters must be installed in a suitable enclosure to meet installation codes stipulated in the Canadian Electrical Code (CEC).


 Revision date:
 Version Revision
 Page:

 2011-02-01
 V3R0
 7/10



WWW PRELECTRONICS COM

# Connection with power supply and barrier built into receiver. Output: Standard 4 - 20mA loop



#### Warning:

Substitution of components may impair intrinsic safety.

The Transmitters must be installed in a suitable enclosure to meet installation codes stipulated in the Canadian Electrical Code (CEC).

Revision date:	Version Revision	Page:
2011-02-01	V3R0	8/10



**Displays** Programmable displays with a wide selection of inputs and outputs for display of temperature, volume and weight, etc. Feature linearisation, scaling, and difference measurement functions for programming via PReset software.



Ex interfaces Interfaces for analogue and digital signals as well as HART® signals between sensors / I/P converters / frequency signals and control systems in Exzone 0, 1 & 2 and for some modules in zone 20, 21 & 22.



**Isolation** Galvanic isolators for analogue and digital signals as well as HART® signals. A wide product range with both loop-powered and universal isolators featuring linearisation, inversion, and scaling of output signals.



**Temperature** A wide selection of transmitters for DIN form B mounting and DIN rail modules with analogue and digital bus communication ranging from application-specific to universal transmitters.



**Universal** PC or front programmable modules with universal options for input, output and supply. This range offers a number of advanced features such as process calibration, linearisation and auto-diagnosis.







www.prelectronics.fr
sales@prelectronics.fr





www.prelectronics.de





www.prelectronics.es sales@prelectronics.es





www.prelectronics.it sales@prelectronics.it





www.prelectronics.se sales@prelectronics.se





www.prelectronics.co.uk ▼ sales@prelectronics.co.uk





www.prelectronics.com





www.prelectronics.cn

#### **Head office**

Denmark PR electronics A/S Lerbakken 10 DK-8410 Rønde

www.prelectronics.com sales@prelectronics.dk tel. +45 86 37 26 77 fax +45 86 37 30 85







